M&P HandALL® HYBRID INSTALLATION PROCEDURE

If you have any problems, don't hesitate to call us.

HOGUE

HOGUE®, INC. P.O. BOX 91360 HENDERSON, NV 89009 1-800-438-4747

Hoqueinc.com

 Before starting to work. MAKE SURE YOUR FIREARM IS UNLOADED and made safe with

magazine removed.

SRD

boiling water or a hair dryer. This will make the grip easier to work with.

Wetting the inside of the HandALL grip first with an evaporative liquid such as glass cleaner or rubbing alcohol will act as a lubricant and make the installation process much easier.

3. If the installation is to take place in a cold

environment, warm the HandALL with hot or



4. Start by hooking the HandALL on the front



bottom corner of the pistol. Rotate onto the frame and push/pull into place until the integral backstrap is seated.



5. Re-install the frame tool into the bottom of the arip.



To Remove the HandALL

1. First remove the frame tool from the frame. Next, apply window cleaner or rubbing alcohol between the frame and grip. This will act as a lubricant and make the removal process much easier. Use a 5/16" (8mm) allen wrench or similar tool to lift the backstrap out and away from the frame pocket in the back of the pistol, at the same time twist and pull the HandALL down and off the pistol.



IMPORTANT!

Check all functions of your firearm after grips are installed. Test-fire your firearm. This is especially important if weapon is to be used for law enforcement duty.



2. Follow the manufacturer's instructions and remove the frame tool and backstrap insert from the pistol.